

Roll-on Lip Gloss with PureSyn™ 150

Viscosity = 300 cP

Description

PureSyn™ 150 provides enhanced shine and emolliency in this Liquid Roll-On Lip Gloss for dry lips.

<u>Phase</u>	<u>Ingredient</u>	<u>INCI Designation</u>	<u>Wt%</u>
A	Mineral Oil (Light)	Mineral Oil	37.68
A	PureSyn 150	Hydrogenated Polydecene	60.00
B	Aloe Oil Extract, Mineral	Mineral Oil (and) Aloe Barbadensis Leaf	0.10
C	Vanilla Lemon Chiffon UU-24	Flavor	0.50
D	Menthol	Menthol	0.25
E	Vitamin E Acetate	Tocopheryl Acetate	.20
F	D&C Red # 28 (0.1% in oil)	Red 28	1.27
	Total		100.00

Blending Procedure

1. Heat phase A to 70°C.
2. Cool to 60°C and add remaining ingredients.
3. Pour mixture into container at ambient temperature.

CLI 1661901

This experimental personal care formulation is provided for illustrative purposes only. It is neither tested nor represented as suitable for cosmetic, medical or pharmaceutical uses or freedom from patent infringement. This formulation has not been subject to comprehensive safety testing. It is the user's responsibility to thoroughly test any formulation before use in any specific applications.

150133 - Updated November 2006